




MANUAL



ENGLISH

CDMP-150 MKII

Ordercode: D1153

Table of contents

Warning	2
Unpacking Instructions.....	2
Safety Instructions	2
Operating Determinations	3
Connection with the mains.....	3
Return Procedure.....	4
Claims.....	4
Description of the device	4
Overview	4
Front.....	5
Back.....	5
Remote control	6
Installation	6
Set Up and Operation	7
Names and functions	7
Operations	10
Loading a CD	10
Unloading CD's	10
Starting playback.....	10
Stop playback	10
Selecting tracks	10
Selecting Folders	10
Pausing.....	11
Scanning Fast forward	11
Scanning Fast backwards	11
Cueing	11
Auto Cue	11
Repeat mode	11
Time display.....	11
Changing pitch of the song	12
Loop play.....	12
Reloop.....	12
Program play	12
Before switching off the power	13
Maintenance	13
Troubleshooting	13
Product Specification	14

Warning



**For your own safety, please read this user manual carefully
before your initial start-up!**



Unpacking Instructions

Immediately upon receiving this product, carefully unpack the carton and check the contents to ensure that all parts are present, and have been received in good condition. Notify the dealer immediately and retain packing material for inspection if any parts appear damaged from shipping or the carton itself shows signs of mishandling. Save the carton and all packing materials. In the event that a device must be returned to the factory, it is important that the device is returned in the original factory box and packing.

Your shipment includes:

- DAP CDMP-150 MKII
- Stereo RCA cable 1,2m
- Power cable 1,5m
- User manual



CAUTION!

**Keep this device away from rain and moisture!
Unplug mains lead before opening the housing!**



Safety Instructions

Every person involved with the installation, operation and maintenance of this system has to:
be qualified
follow the instructions of this manual



**CAUTION! Be careful with your operations.
With a dangerous voltage you can suffer
a dangerous electric shock when touching the wires!**



Before you initial start-up, please make sure that there is no damage caused by transportation. Should there be any, consult your dealer and do not use the system.

To maintain perfect condition and to ensure a safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes written in this manual.

Please consider that damages caused by manual modifications to the system are not subject to warranty.

This system contains no user-serviceable parts. Refer servicing to qualified technicians only.

IMPORTANT:

The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorized modification to the system.

- Never let the power-cord come into contact with other cables! Handle the power-cord and all connections with the mains with particular caution!
- Never remove warning or informative labels from the unit.
- Never use anything to cover the ground contact.
- Never leave any cables lying around.
- Do not insert objects into air vents.
- Do not connect this device to a dimmerpack.
- Do not switch the device on and off in short intervals, as this would reduce the system's life.
- Do not open the device and do not modify the device.
- Only use system indoor, avoid contact with water or other liquids.
- Avoid flames and do not put close to flammable liquids or gases.
- Always disconnect power from the mains, when the system is not used. Only handle the power-cord by the plug. Never pull out the plug by tugging the power-cord.
- Make sure you don't use the wrong kind of cables or defective cables.
- Make sure that the available voltage is not higher than stated on the rear panel.
- Make sure that the power-cord is never crimped or damaged. Check the device and the power-cord from time to time.
- Please turn off the power switch, when changing the power cord or signal cable.
- If the device is dropped or struck, disconnect mains power supply immediately. Have a qualified engineer inspect for safety before operating.
- If the device has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation water might damage your system. Leave the device switched off until it has reached room temperature.
- If your Dap Audio device fails to work properly, discontinue use immediately. Pack the unit securely (preferably in the original packing material), and return it to your Dap Audio dealer for service.
- Repairs, servicing and electric connection must be carried out by a qualified technician.
- WARRANTY: Till one year after date of purchase.

Operating Determinations


- This device is not designed for permanent operation. Consistent operation breaks will ensure that the device will serve you for a long time without defects.
- The minimum distance between light-output and the illuminated surface must be more than 0.5 meter.
- The maximum ambient temperature $t_a = 45^{\circ}\text{C}$ must never be exceeded.
- The relative humidity must not exceed 50 % with an ambient temperature of 35°C .
- If this device is operated in any other way, than the one described in this manual, the product may suffer damages and the warranty becomes void.
- Any other operation may lead to dangers like short-circuit, burns, electric shock, crash, etc.

You endanger your own safety and the safety of others!

Connection with the mains

Connect the device to the mains with the power-plug.

Always pay attention, that the right color cable is connected to the right place.

International	EU Cable	UK Cable	US Cable	Pin
L	BROWN	RED	YELLOW/COPPER	FASE
N	BLUE	BLACK	SILVER	NULL
	YELLOW/GREEN	GREEN	GREEN	EARTH

Make sure that the device is always connected properly to the earth!

Improper installation can cause serious damage to people and property!

⚠ Return Procedure ⚠

Returned merchandise must be sent prepaid and in the original packing, call tags will not be issued. Package must be clearly labeled with a Return Authorization Number (RMA number). Products returned without an RMA number will be refused. Highlite will not accept the returned goods or any responsibility. Call Highlite 0031-455667723 or mail aftersales@highlite.nl and request an RMA prior to shipping the fixture. Be prepared to provide the model number, serial number and a brief description of the cause for the return. Be sure to properly pack fixture, any shipping damage resulting from inadequate packaging is the customer's responsibility. Highlite reserves the right to use its own discretion to repair or replace product(s). As a suggestion, proper UPS packing or double-boxing is always a safe method to use.

Note: If you are given an RMA number, please include the following information on a piece of paper inside the box:

- 01) Your name
- 02) Your address
- 03) Your phone number
- 04) A brief description of the symptoms

Claims

The client has the obligation to check the delivered goods immediately upon delivery for any shortcomings and/or visible defects, or perform this check after our announcement that the goods are at their disposal. Damage incurred in shipping is the responsibility of the shipper; therefore the damage must be reported to the carrier upon receipt of merchandise.

It is the customer's responsibility to notify and submit claims with the shipper in the event that a fixture is damaged due to shipping. Transportation damage has to be reported to us within one day after receipt of the delivery.

Any return shipment has to be made post-paid at all times. Return shipments must be accompanied with a letter defining the reason for return shipment. Non-prepaid return shipments will be refused, unless otherwise agreed in writing.

Complaints against us must be made known in writing or by fax within 10 working days after receipt of the invoice. After this period complaints will not be handled anymore.

Complaints will only then be considered if the client has so far complied with all parts of the agreement, regardless of the agreement of which the obligation is resulting.


Description of the device

Features


The CDMP-150 MKII is a professional 1U CD/USB/MP3/WAV player from DAP Audio.

- LCD display with blue backlight
- Pitch control +/- 16%
- Electronic anti shock buffer (40 seconds)
- Seamless loop function
- Cue function
- Program function
- USB stick/hard disk port

Overview




Front





- ① Power switch
- ② Disc slot
- ③ Eject button
- ④ LCD display
- ⑤ Track select encoder
- ⑥ Rewind button
- ⑦ Fast forward button
- ⑧ Loop in button + LED
- ⑨ Loop out button + LED
- ⑩ Loop reloop button
- ⑪ Pitch Reset control
- ⑫ CD load LED
- ⑬ USB jack
- ⑭ Disc/USB select
- ⑮ Back button
- ⑯ CUE button
- ⑰ Play/Pause button
- ⑱ Repeat button
- ⑲ Single button
- ⑳ Time button
- ㉑ Pitch (-) button
- ㉒ Pitch button
- ㉓ Pitch (+) button

Back



- ⑳ Phones output
- ㉑ Phones level control
- ㉒ Balanced Output L/R
- ㉓ Un-balanced output L/R
- ㉔ Digital output
- ㉕ Fader start
- ㉖ Power entrance

Remote control



- 31 Eject button
- 32 Repeat button
- 33 Previous button
- 34 Time button
- 35 Cue button
- 36 Search (-) button
- 37 Search (+) button
- 38 Pitch bend (-) button
- 39 Pitch bend (+) button
- 40 Pitch button
- 41 Brake button
- 42 PGM button
- 43 Volume (+)
- 44 Enter button
- 45 Next button
- 46 Single / Continuous button
- 47 Volume (-)
- 48 Play/pause button
- 49 Stop button
- 50 Skip (-) button
- 51 Skip (+) button
- 52 REC cue point A or B
- 53 Call cue point A or B
- 54 Cue point A
- 55 Cue point B
- 56 Direct access buttons
- 57 A. Cue button
- 58 Source button

Installation

Remove all packing materials from the CD Player. Check that all foam and plastic padding is removed. Connect all cables.

Always disconnect from electric mains power supply before cleaning or servicing.
Damages caused by non-observance are not subject to warranty.

Set Up and Operation

Before plugging the unit in, always make sure that the power supply matches the product specification voltage. The power supply is printed on the back of the device.
Do not attempt to operate a 120V specification product on 230V power, or vice versa.

Connections

- 01) Turn off the **power (1)** switch.
- 02) Connect the **line out L/R (26 or 27)** outputs to the input of your mixer.

Caution: Be sure that the power is off, when connecting the cables.

Names and functions

Below is a description of the functions of the controls.

1. Power switch

This is the main power switch. Push to turn the device on.

2. Disc slot

Place the disc gently in the slot. The disk will load automatically. Stop playback and press the **eject (3/44)** button to eject the disk.

3/31. Eject button

Use this button to eject the disc. The disc can't be ejected during Playback. Pause playback before pushing the eject button.

4. LCD Display

5/50+51. Track select encoder

Dialing the encoder clockwise, allows you to skip a track forwards, dialing counterclockwise will skip a track backwards.

Pushing the encoder when in playback mode, allows you to skip 10 tracks forwards or backwards.

Pushing and holding while dialing the encoder, allows you to select a folder when in MP-3 mode.

6/36. Search ◀◀ button

Push and hold this button to play the track fast backwards.

7/37. Search ▶▶ button

Press and hold this button to play the track fast forward.

8. Loop in button

The loop in button allows you to set the start point for the loop.

9. Loop out button

The loop out button allows you to set the end point for the loop. Pushing the button again, allows you to exit the loop.

10. Re-loop button

Use this button to start the last saved Loop. Push the **loop out (9)** button to exit the loop playback.

11. Pitch control encoder

Use this encoder to adjust the playback speed. Dial the control counterclockwise to slowdown the playback speed, dial the control to speed up the playback speed. Press the button to reset the pitch encoder.

12. CD load LED

This LED blinks while loading the CD.

13. USB port

Use this port to connect a USB stick or an external hard disk. The USB port is only active when you're in USB mode.

Note: The CDMP-150 MKII recognizes FAT and NTFS format up to a maximum capacity of 64 Gb, 99 folders and 999 files.

14/58. CD/USB (source) button

Use this button to select CD or USB mode.

15. Back button

Showing executive folder and the songtitle (Folder name – Song Titel – State).

16/35. Cue button

Push this button during playback to return to the position of the last cue point.

17/48. Play/pause ►/|| button

This button allows you to toggle between pause mode and playback mode.

18/32. Repeat button

Use this button to repeat one track or all tracks of the medium. See the section **Repeat mode** on page 11.

19/46. Single (S/C) button

Use this button to switch between the single play mode and continuous play mode.

The selected mode is indicated by *Single* or *Cont.* in the **LCD display (4)**.

In single play mode, the unit stops playing after each track.

In continuous play mode, the unit plays all tracks and then stops.

20/34. Time button

Use this button to switch the *TIME* indication in the **LCD display (4)** between the elapsed time and remaining time. The selected mode is indicated by *ELAPSED* or *REMAIN*.

21/38. Pitch bend – button

The playback slows down while pushing and holding this button. Release the button to return to the original BPM. Make sure pitch bend mode is activated by pushing the **pitch (22/40)** button.

22/40. Pitch button

This button allows you to toggle the pitch mode on or off. In pitch mode, you are able to use the **pitch bend + (23/52)** and **pitch bend – (21/55)** buttons. Pitch mode will be indicated in the **LCD display (4)**.

23/39. Pitch bend + button

The playback speeds up while pushing and holding this button. Release the button to return to the original BPM. Make sure pitch bend mode is activated by pushing the **pitch (22/40)** button.

24. Phones output

You can connect a pair of headphones with an impedance of 32 - 600 Ohm to the headphones connector. It is a 6,3mm (1/4") TRS socket, wired as Tip=left, Ring=right and sleeve = ground.

25. Phones level control

Is used to adjust the volume level of the **phones (25)** output.

26. Balanced line out L/R

XLR stereo line output. Use these outputs to connect to a mixer with balanced XLR inputs.

27. Unbalanced line out L/R

RCA stereo line output. Use these outputs to connect to a mixer with unbalanced RCA inputs.

28. Digital output

Coaxial digital output signal.

29. Fader start

External control to active the start/pause button.

30. AC power entrance

This connector is meant for the connection of the supplied main cord. Connect one end of the power cord to the connector, the other end to the mains, then turn on the power switch to operate the unit.

33. Previous folder button

Press this button to skip to the previous folder's first track.

41. Brake button

Pushing and holding this button while dialing the jog wheel allows you to set the start/break time between 0,5 and 6 seconds. Arm the brake function by pushing the **brake (41)** button, the **brake (41)** button lights up red indicating the brake function is armed. Pushing the **play/pause (17/48)** button will actually trigger the start/break function.

42. PGM button

Stop playback and press the PGM button, the player will enter the program mode. For more information, see the section **Program play** on page 12.

43. Volume (+)

Press the VOL+ button to increase the volume.

44. Enter/Select button

Press this button to enter/select a folder.

45. Next folder button

Press this button to skip to the next folder's first track.

47. Volume (-)

Press the VOL- button key to decrease the volume.

49. Stop button

Press this button to stop playback.

52. REC Cue point A or B

Record cue-point A or B

53. CALL Cue point A or B

Recall cue-point A or B

54. Cue point A

Set Cue point A

55. Cue point B

Set Cue point B

56. Direct access buttons

Use these buttons to select a track directly. Use the +10 button to move up 10 tracks. E.g. if your actual track is 5, pushing the +10 button will select track 15.

57. A. Cue button

When pressed for over 2 seconds, auto cue turns on and off. When **A. CUE** is pressed again for at least 2 seconds, auto cue is set to off.

Operations

Loading a CD

Hold the disc by the edges and push it gently in the **disc slot (2)**. The Disc will now be loaded automatically.

Unloading CD's

- 01) The disc can't be ejected during playback. Stop the playback first.
- 02) Press the eject **(3/31)** button. The disc will be ejected.
- 03) If the movement of the disc stops, take the disc by the edges and remove it completely from the slot.

CAUTION:

- Do not place any foreign objects in the disc slot and do not try to place more than one disc in the disc Slot at a time.
- Do not push the disc in manually when the power is off, as this may result in malfunction and may damage the player.

CD's/ WAV-USB Sticks / MP3-discs/ USB sticks

MP3 is an audio compression mode using level 3 of the international MPEG standard, whereby the sound signal is compressed at the ratio of 12:1. An MP3 disc can record music for playback over 600 minutes or record over 170 songs in a sound quality that fully matches the sound quality of CD's. An USB stick can record even more. Obviously the CDMP-150 MKII works also with normal audio CD's.

Starting playback

- Push the **play/pause (17/46)** button during the pause mode or cue mode to start playback. While in playback mode, the LED in the **play/pause (17/46)** button lights up green.
- If the search buttons are used during pause mode, the point at which playback starts is automatically stored in the memory as the cue point. The CD Player returns to the cue point when the **cue (16/34)** button is pressed.

Stop playback

There are two ways to stop playback:

- Push the **play/ pause (17/46)** button while in playback mode to pause at that point.
- Push the **cue (16/34)** button during playback to return to the cue point and enter pause mode.

Selecting tracks

- Dial the **track (5)** encoder clockwise to move to a higher track number.
- Dial the **track (5)** encoder counterclockwise to move to a lower track number.
- When a new track is selected during playback, playback begins as soon as the skip search operation is completed.
- If you dial the **track (5)** encoder clockwise while at the last track, the first track will be selected. In the same way, if you dial the **track (5)** encoder counterclockwise while at the first track, the last track will be selected.
- Pushing the **track (5)** encoder while playing CD's, allows you to skip 10 tracks forwards or backwards.

Selecting Folders

- In pause mode: Push the **Previous (33)/Next (45)** folder buttons to select a folder, followed by pressing the **Enter/Select (44)** button.
- In Program mode: Push the **Previous (33)/Next (45)** folder buttons to select a folder, followed by pressing the **Enter/Select (44)** button.
- In USB mode: Push the **Previous (33)/Next (45)** folder buttons to select a folder, followed by pressing the **Enter/Select (44)** button.
- In USB mode: Pushing dialing the **track (5)** button at the same time, allows you to select a folder.

Pausing

- Push the **play/pause (17/46)** button to switch between playback mode and pause mode.
- The LED in the **play/pause (17/46)** button will blink while the unit is in pause mode.
- Playback resumes when the **play/pause (17/46)** button is pushed again.

Scanning Fast forward

- Forward Scanning is a function for moving quickly forwards while being in playback mode.
- While pressing and holding the **search ►► (7/47)** button for more than 1 second, the disc moves rapidly forward and the sound is audible. The current scan point is indicated on the LCD.

Scanning Fast backwards

- Backward Scanning is a function for moving quickly backwards while being in Playback mode.
- While pressing and holding the **search ◀◀ (6/38)** button for more than 1 second, the disc moves rapidly backwards and the sound is audible. The current scan point is indicated on the LCD.

Setting a cue point

- Push the **play/pause (17/46)** button to toggle between play mode and pause mode.
- The **play/pause (17/46)** button will flash when the unit is in pause mode.
- Use the **search ◀◀ (6/35)** and/or **search ►► (7/36)** buttons to go to your desired cue point (is necessary).
- Push the **play/pause (17/46)** button again and your cue point has been stored and playback will continue.

Setting a hot cue Point

- Push the play/pause **(17/46)** button to switch between play and pause.
- The play/pause **(17/46)** button will flash when the unit is in pause mode.
- Use the **search ◀◀ (6/35)** and/or **search ►► (7/36)** buttons to go to your desired cue point (is necessary).
- Push the rec **(50)** button and hold it.
- Push the hot cue button (**A (52)** or **B (51)**) in which you want to store your hot cue point.

Cueing

Cueing is the action of preparing for playback.

- Push the **cue (16/34)** button, the player will enter the cue mode, the playback returns to the cue point and enters pause mode condition, the LED in the **play/pause (17/46)** button will blink. Pushing the **play/pause (17/46)** button will start playback from the cue point.

Auto Cue

When a track is loaded or the track search operation is performed, the silent section at the beginning of the track is skipped and the cue point is automatically set at the point immediately before the sound starts.

Repeat mode

Two different repeat modes are available: REPEAT 1 and REPEAT ALL.

When you press **repeat (18, 32)** during playback, you can choose between the following play modes:

- 01) REPEAT 1: Repeats a single track several times.
- 02) REPEAT ALL: Repeats all tracks several times.

Time display

Pushing the **time (20/33)** button allows you to select between 3 time modes:

- 01) Elapsed time of a track (*ELAPSED*).
- 02) Remaining time of a track (*REMAIN*).
- 03) Remaining time of the disc (*TOTAL*). This display mode can only be activated if a disc is formatted as a CD.

Changing pitch of the song

There are three tools available for matching the BPM of the CD:

- **Use the pitch encoder to adjust the BPM.**
 - 01) Adjust the BPM by dialing the **pitch encoder (11)** up or down.
 - 02) Dial the **pitch encoder (11)** counterclockwise to decrease BPM, or clockwise to increase BPM. The adjustment range is +/- 20%.
- **Use the pitch bend buttons to change the BPM temporarily.**
 - 01) The BPM increases or decreases respectively while the pushing the **pitch bend + (23/38)** or **pitch bend - (21/37)** button.
 - 02) The BPM increase depends on how long you hold the button. If you hold the button for about 5 seconds, the BPM will go +20% for **pitch bend + (23/38)** or -20% for **pitch bend - (21/37)**. If you tap the button, the BPM will only change a little so you can change the beat slightly without an audible change in the music.
 - 03) The CD will return to the BPM set with the **pitch encoder (11)** when you release the **pitch bend + (23/38)** and **pitch bend - (21/37)** buttons.

Loop play

- 01) Push the **loop in (8)** button to set the loop start point, the LED beneath the **loop in (8)** button will light up, indicating that the start point is memorized.
- 02) Push the **loop out (9)** button to set the loop end point. The LED beneath the button will light up also. As soon as the end point is set, the playback will start loop play from start point to end point repeatedly. Both the LEDs beneath **loop in (8)** and **loop out (9)** buttons will light and *LOOP* will appear in the LCD display.
- 03) Pushing the **loop out (9)** button will cancel the loop play function, the *LOOP* indication in the **LCD display (2)** will disappear and the LED beneath the **loop out (9)** button will dim.
- 04) The only way to erase a loop is to record a new loop.

Re-loop

- If you press the **re-loop (10)** button, the disc will return to loop playback.
- Push the **loop in (8)** button over and over rapidly to start the loop again and again.
- Push the **loop out (9)** button, the loop play function is canceled, the *LOOP* indication in the **LCD display (2)** will disappear.

Program play

- 01) Push the **play/pause (17/46)** button to enter pause mode.
- 02) Push the **pgm (41)** button, the player will enter program mode, indicated by *PROGRAM* blinking in the **LCD (2)** display.
- 03) Only in MP-3 mode: Select a folder by pushing the **Previous (33)/Next (45)** folder buttons, followed by pressing the **Enter/Select (44)** button.
- 04) Select a track by either pushing the direct **access (53)** buttons or by dialing the **track (5)** encoder.
- 05) Push the **pgm (41)** button to store the selected track in the program sequence.
- 06) Repeat step 3 to 5. A maximum of 99 tracks can be programmed.
- 07) Use the **play/pause (17/46)** button to start or pause program play.
- 08) To exit program play, enter pause mode by pushing the **play/pause (17/46)** button and push the **pgm (41)** button.
- 09) To erase a program, push and hold the **pgm (41)** button more than 3 seconds. The *PROGRAM* indication in the display will disappear.

Before switching off the power

CAUTION:

Do not force the disc in when the power is switched off.
Do not switch off the power, when the disc is ejecting.
Switch off the power after the disc has been ejected.

CD's

1. Precautions on handling compact discs

- Do not allow fingerprints, oil or dust to get on the surface of the disc. If the disc is dirty, wipe it off with a soft dry cloth.
- Do not use thinner, water, record spray, electrostatic-proof chemicals, or silicone-treated cloths to clean discs.
- Always handle discs carefully to prevent damaging the surface; in particular when removing a disc from its case or returning it.
- Do not bend the disc.
- Do not put the CD near heating sources.
- Do not enlarge the hole in the center of the disc.
- Do not write on the label (printed side) with a hard-tipped implement such as a pencil or ball point pen.
- Condensation will form if a disc is brought into a warm area from a colder one, such as outdoors in winter. Do not attempt to dry the disc with a hair dryer, etc.

2. Precaution on storage

- After playing a disc, always unload it from the player.
- Always store the disc in the jewel case to protect from dirt or damage.
- Do not place discs in the following areas:
 - 01) Areas exposed to face sunlight for a considerable time.
 - 02) Areas subject to accumulation of dust or high humidity.
 - 03) Areas that are affected by heat from indoor heaters, etc.

Maintenance

The DAP Audio-CD-Player CDMP-150 MKII requires almost no maintenance.

However, you should keep the unit clean. Disconnect the mains power supply, and then wipe the cover with a damp cloth. Do not immerse in liquid. Do not use alcohol or solvents.

Keep connections clean. Disconnect electric power, and then wipe the audio connections with a damp cloth. Make sure connections are thoroughly dry before linking equipment or supplying electric power.

Troubleshooting

DAP Audio-CD-Player CDMP-150 MKII


This troubleshooting guide is meant to help solve simple problems. If a problem occurs, carry out the steps below in sequence until a solution is found. Once the unit operates properly, do not carry out following steps.

- 01) If the device does not operate properly, unplug the device.
- 02) Check power from the wall, all cables, connections, etc.
- 03) If all of the above appears to be O.K., plug the unit in again.
- 04) If nothing happens after 30 seconds, unplug the device.
- 05) Return the device to your DAP Audio dealer.

Product Specification

Pitch:	20%
Pitch bend:	20%
Loop:	Seamless
S/N ratio:	96 dB
Compatible disks:	CD, CDR, CDRW, Audio & Data (WAV & MP3 files)
USB files:	MP3/WAV, max 99 folder, 999 files
USB format:	FAT, NTFS max 64Gb
Anti-shock buffer:	40 Sec
Remote batteries:	2x AAA (not included)
Power supply:	100-240V 50/60Hz
Power consumption:	16W
Dimensions:	482 x 225 x 45 (WxDxH)
Weight:	2.9 Kg

Dimensions



Design and product specifications are subject to change without prior notice.



Website: www.Dap-audio.info
 Email: service@highlite.nl



©2014 DAP Audio